


### WS300-LED

Fixture Height: 8 in. (20.32 cm)  
 Fixture Width: 2.25 in. (5.71 cm)  
 Fixture Depth: 3.5 in. (8.89 cm)



1. Drill hole for wire run
2. Insert hexagonal screw into back of mounting plate
3. Mount backplate to the surface
4. Feed wire through backplate and mounting surface
5. Fasten hexagonal nuts to hexagonal screws (from step 2)

